

Electric Pathway String Lights Assembly Instructions

It's so Easy to Use!

- Attach Bulb Socket to Pathway Stake and tuck cord into catch on both sides. This will hold String Light in upright position.
- Push Pathway Stake into the ground securely at desired location.

- 10 Bulb String is 30 feet long with 36 inches between each bulb.
- Up to 3 String Lights can be connected end to end.
- Steady illuminating - stays lit if one bulb burns out.
- Replaceable fuse plug.



Secure cord in Pathway Stake channel



Lock in position and slide Bulb/Socket down

Decorative for Holidays and Special Events

- Ideal for Christmas, Halloween, parties, picnics, weddings and family gatherings.
- It's a great way to welcome your guests.

Use Outdoors

- For use along sidewalk, walkways, yard, garden bed and driveway.



⚠ CAUTION - THIS IS AN ELECTRIC PRODUCT – NOT A TOY! TO AVOID RISK OF FIRE, BURNS, PERSONAL INJURY AND ELECTRIC SHOCK IT SHOULD NOT BE PLAYED WITH OR PLACED WHERE SMALL CHILDREN CAN REACH IT.

⚠ WARNING - NEVER LEAVE PRODUCT UNATTENDED WHILE PLUGGED IN. READ IMPORTANT SAFETY INSTRUCTIONS AND CAUTIONS INSIDE. DO NOT LET BULBS CONTACT DRAPES, CARPETING, UPHOLSTERY, BEDDING OR ANYTHING THAT WILL BURN. HOT SURFACE! DO NOT TOUCH BULBS WHILE LIT, ALLOW BULBS TO COOL FIRST. DO NOT DECORATE OR HANDLE WHILE PLUGGED IN, MAY DAMAGE BULB CAUSING INCREASED TEMPERATURE.



JHSpecialties, Inc., Exton, PA 19341
www.lumabase.com Made in CHINA